# Data Sheet TouchMonitor TM3 | TM3 Smart









# TouchMonitor TM3 | TM3 Smart



Flexible touch screen layout • Loudness: EBU, ITU, ATSC, ARIB, OP-59, AGCOM, CALM • LRA • PPM/True Peak • SPL Stereo/6-channel operation • Dialnorm • Analog, S/PDIF, AES3 • Modular software • Moving Coil • Timecode • Chart

TouchMonitor TM3 is an exceptionally budget-friendly metering solution for applications including editorial working environments, edit suites and smaller control rooms, to name but a few. It consists of a display unit with 4.3" touch screen that can be used either vertically or horizontally and a separate interface box.

TM3 features PPM and true peak measurements as well as comprehensive loudness measurement functions such as single-channel and summing bargraphs, loudness range, loudness chart, and numerical displays that conform to all relevant global standards (EBU R128, ITU BS.1770-3/1771-1, ATSC A/85, ARIB, OP-59, AGCOM, and CALM).

The straightforward user interface allows for quick and simple preset selection. Presets can be configured in detail using the Devicer DC1 software for Mac OS X® or Windows®. The Devicer's GUI lets you select, configure and position the instruments you need in a convenient way. The screen layout can be previewed at any time to see how your preset will look like on the TM3.

While the stereo version TM3 works with analog or digital signals, model TM3 Smart (TM3S) processes six digital input channels in parallel. This feature can be retrofitted to stereo versions any time. With the Moving Coil licence option, stereo signals can also be displayed on needle instruments.

TM3. Loudness Simplified.

# Hardware

#### **TM3**

- 2-channel Stereo version for Peak, TruePeak, correlation and Loudness measurements, expandable with software modules (licences)
- Table-top unit with display unit and remote interface box (cable length 2 m), with mains adapter
- 4.3" touch screen (272 x 480 pixel)
- Analog stereo input via RCA (unbalanced, with potentiometer adjustable in the range from 150 mV to 30 V) or via 25 pin Sub-D (balanced, +4/+6 dBu, with software adjustable in the range from 0 to +10 dBu)
- Digital Stereo in- and output via RCA (S/PDIF) or via 25 pin Sub-D (balanced, AES3)
- USB 2.0, GPIO, 24 V DC connectors
- Loudness metering acc. to EBU R128, ITU-R BS.1770-3/ 1771-1, ATSC A/85, ARIB, OP-59, AGCOM, CALM, or customer specific
- Loudness Test Time Control
- Loudness Range (LRA) and SPL display
- Comprehensive set of presets, easy recall
- Personalizing with **Devicer DC1** (Device Configurator software for Windows® and Mac OS X®)

#### TM3 Smart (TM3S)

- 6-channel version for Peak, TruePeak, correlation and Loudness measurements, equipped with all licences
- Table-top unit with display unit and remote interface box (cable length 2 m), with mains adapter
- 4.3" touch screen (272 x 480 pixel)
- Analog stereo input via RCA (unbalanced, with potentiometer adjustable in the range from 150 mV to 30 V) or via 25 pin Sub-D (balanced, +4/+6 dBu, with software adjustable in the range from 0 to +10 dBu)
- Digital Stereo in- and output via RCA (S/PDIF)
- Three digital Stereo in- and output via RCA (S/PDIF) or via 25 pin Sub-D (balanced, 3 x AES3)
- USB 2.0, GPIO, 24 V DC connectors
- Loudness metering acc. to EBU R128, ITU-R BS.1770-3/ 1771-1, ATSC A/85, ARIB, OP-59, AGCOM, CALM, or customer specific
- Loudness Test Time Control, Loudness Chart
- Loudness Range (LRA) and SPL display
- Dialnorm measurement, Timecode Reader, Moving Coil
- Comprehensive set of presets, easy recall
- Personalizing with **Devicer DC1** (Device Configurator software for Windows® and Mac OS X®)









### **Additional Hardware Options**

TM3-2U (option for 2U rack mounting)

Option for mounting TM3/TM3S into rack frame TM3-MA2U or into other appropriate mechanical environments. It can only be ordered together with a TM3, or TM3S devices. Then, a display with mounting frame, mounting material, and an USB extension cable is part of delivery.

TM3-MA2U (2U rack carrier for TM3/TM3S with TM3-2U)

19"/2U rack carrier/mounting frame to be fitted with up to two TM3 series units which must feature the TM3-2U option.

# Software


# (Basic) Software

Every TM3 comes with a (basic) software package. Beside the signal processing and the control functions this software includes a 2-channel (TM3) or multi-channel (TM3S) Program Meter for measuring peak level, True Peak and Loudness (digital scales, peak hold, peak memory, Over indicators), the Loudness Sum instrument for measuring the summed loudness (M, S, I values), the LRA instrument for the graphical display of the Loudness Range, numerical displays of all

relevant loudness values, a phase correlation meter, and a global keyboard for simultaneous control of defined functions in multiple instruments and for preset recall. It also allows the external control with the integrated GP IO interface. Optionally, different software modules are available as licences for TM3. Model TM3 Smart (TM3S) is fully equipped with these licences already and additionally features a Dialnorm meter and the Loudness Chart instrument.

# **Devicer DC1**

By default, the TM3's TM3S's preset memorys contain comprehensive sets of factory presets covering many common applications. The Devicer DC 1 used to personalize the presets is available free of charge on the RTW web site. The Devicer's GUI lets you select, configure and position the instruments you need in a convenient way. The screen layout can be previewed at any time to see how your preset will look like on the TM3 or TM3S. After having installed this Device Configurator software on your Mac OS X® (10.6. to 10.9.) or Windows® (7/8) computer, the TM3 or TM3S is connected to it using an USB cable (Mini-B / A). After all edits are performed and saved in the Devicer DC1, the respective presets can be uploaded to the TM3 or TM3S.



Windows is either registered trademark or trademark of Microsoft Corporation in the United States and/or other countries. Mac OS is trademark of Apple Inc., registered in the U. S. and other coutries.

# Software (continued)

# **Software Modules (Licences)**

Current software modules for TM3 can be ordered as licences either together with the ordered TM3 version or at a later point in time.

Together with the order of the unit a licence will be activated at delivery.

When a licence is needed at a later point in time, a devicespecific file for forwarding to RTW is created by the unit. RTW will send back a corresponding file with the activated licence for exactly this unit.

On TM3 Smart, these licences are completely activated.

#### TM3-SW6UPG: 6-channel Upgrade

This option expands the feature set of the TM3 to allow 6-channel signal processing and Dialnorm measurement. (On TM3 Smart already active).

#### TM3-SWTCR: Timecode Reader

This option expands the feature set of the TM3 to allow external timecode signals to be decoded, displayed and used for additional functions.

Functions: Timecode reader and display of an external analog or digital source.

(On TM3 Smart already active).

#### TM3-SWMC: Moving Coil

This option expands the feature set of the TM3 with the Moving Coil instrument for the display of needle instruments for up to 2-channel Stereo with different scales. Functions: L/R and M/S PPM modes (BR IIa/BR IIb scales), VU mode, Loudness mode, dual or single (stereo) displays horizontal or vertical, a combined mode with Dual-PPM and Loudness sum display (BBC) is also available. (On TM3 Smart already active).

#### TM3-SWB1: Software Bundle (Licence Upgrade)


This option expands the feature set of the TM3 with the licences TM3-SW6UPG, TM3-SWMC, and TM3-SWTCR, and with the Loudness Chart instrument for displaying the course over time of a loudness measurement. If the corresponding licence upgrade (software bundle) has been installed, upcoming instruments and functions can easily be added via firmware update.

Upgrade functions: completely equate to the licences described on the left.


Loudness Chart instrument functions: graph with course over time of one of the measured loudness values TP, M, S, or I, switchable Relative Gate view, adjustable time ranges, switchable Integrated bargraph, adjustable tolerance levels. (On TM3 Smart already active).

# **Dimensions**

# Display Unit TouchMonitor TM3, TM3 Smart




# Interface Box TouchMonitor TM3, TM3 Smart



# **Dimensions (continued)**

#### Option TM3-2U


(can only be ordered together with a TM3, or TM3S – allows mounting into front panels/mounting plates or into optional 19"/2U rack carrier/mounting frame TM3-MA2U)



# **Dimensions (continued)**

# Option TM3-MA2U

(separate available 19"/2U rack carrier/mounting frame for mounting up to two TM3/TM3S equipped with TM3-2U option)




1 | Schematic diagram of mounting a TM3 or TM3S with option TM3-2U into 19"/2U rack carrier TM3-MA2U

# Connection

#### **Connectors**

ATTENTION! - For operating the TM3 and TM3 Smart (TM3S), an appropriate mains adapter is required. RTW recommends the use of the RTW wide voltage power supply 1178-R (100 - 240 V AC/24 V DC, 2.7 A) approved for TouchMonitor. This power supply is included in the TM3 and TM3 Smart (TM3S) package.



#### Pin Assignment

#### Analog In L, Analog In R (unbalanced, RCA-F)

Pin: Function:

Pin: Signal

Shield/chassis Ring:



(External view of the connector)

NOTE - The input sensitivity for 0 dB reading is adjustable in the range from 150 mV to 30 V.

While using the RCA connectors, the corresponding inputs of the Sub-D connector cannot be used.

#### Digital In, Digital Out (S/PDIF, unbalanced, RCA-F)

Pin: Function:

Pin: Signal

Shield/chassis Rina:



(External view of the connector)



**NOTE -** The S/PDIF input is permanently terminated with 75  $\Omega$ .

#### 24 V DC (4-pin locking low voltage, type Binder 710)

Pin: Function:

+24 V DC +24 V DC 2

3 0 V 4 0 V

Pin 3 Pin 4



Pin 2 Pin 1

(External view of the connector)

NOTE - An external overcurrent protective device (2 A max.) shall be installed when using an external 24 V DC power supply!

### **USB Mini-B**

10

Full Speed USB 2.0 interface for connecting the TM3 or TM3S unit to the computer using a standard USB data cable. The USB interface is used for the data exchange between Device Configurator software Devicer DC1 and TM3 or TM3S.

#### **Sub-D connector** (25-pin Sub-D-F)

Pin: Function:

Analog input R (+, hot) 1 Analog input R (-, cold) 14 Shield/chassis 15 Analog input L (+, hot) 3 Analog input L (-, cold) 16 Shield/chassis Digital output 3 (+, hot) 4 17 Digital output 3 (-, cold) Shield/chassis

18 Digital output 2 (+, hot)

6 Digital output 2 (-, cold) Shield/chassis

Digital output 1 (+, hot)

20 Digital output 1 (-, cold) Shield/chassis

21 Digital input 3 (+, hot)

9 Digital input 3 (-, cold)

22 Shield/chassis 10

Digital input 2 (+, hot) 23 Digital input 2 (-, cold)

Shield/chassis 11

Digital input 1 (+, hot)

12 Digital input 1 (-, cold)

Shield/chassis

not used

Pin 1 Pin 14 Pin 2 Pin 15 () () () Pin 3 Pin 16 Pin 4 Pin 17 Pin 5 Pin 18 Pin 6 Pin 19 Pin 7 Pin 20 Pin 8 Pin 21 Pin 9 ٥ Pin 22 Pin 10 Pin 23 Pin 11 0,0 Pin 24 Pin 12 Pin 25 Pin 13

(External view of the connector)

**NOTE -** The AES3 inputs are permanently terminated with 110  $\Omega$ . While using the analog inputs of the Sub-D connector, the corresponding analog RCA input connectors cannot be used.

#### GPIO (RJ-12-6P6C socket)

External control of functions and presets recall as defined in the Global Keyboard menu. The inputs defined as "active low" have to be switched against 0 V (Pin 1).


Pin: Function:

2 - 6 Function acc. to definition in the menu



(External view of the connector)

#### Block diagram of the GPIO interface



# Specifications

#### System

General

Power requirements: +24 V DC (external 2 A max. overcurrent

protective device shall be installed!)

Current drain: 160 mA nominal, power-up current is much higher Display: Capacitive 4.3" touch screen (272 x 480 pixel)

Connectors: 1 x 4-pin locking low voltage connector type Binder 710 (DC)

> 1 x USB Mini-B; USB 2.0 Full Speed connectors for data exchange between Devicer DC1 computer software and TM3

> 1 x GPIO (RJ-12-6P6C) for defined functions or preset recall

2 x RCA-F (unbalanced, analog inputs) 2 x RCA-F (unbalanced, S/PDIF in-/output)

1 x 25-pin Sub-D-F (balanced, alternative analog, up to 3 x AES3 in-/outputs)

82.5 x 138 x 50 mm Dimensions (W x H x D): Display unit: 146 x 29 x 85 mm Interface box:

Display unit approx. 320 g, interface box approx. Weight:

460 g, w/o mains adapter Operating temperature: +5° to +40° C

Functions (range depending on the specific unit type)

· Instruments can be scaled and freely positioned

PPM up to 6 channels

Loudness-Meter: ITU-R BS.1770-3/1771-1. EBU R128, ATSC A/85, ARIB, OP-59, AGCOM, CALM, custom mode

Loudness Test Time Control

Loudness Range instrument (LRA)

Loudness Chart instrument, SPL meter

Stereo Correlator

Dialnorm (w/o speech intelligence)

AES3 status monitor

Numerical displays

Moving Coil instruments, Timecode Reader

**Analog Inputs** 

2 analog inputs, 2 x RCA or alternativ via 25-pin

via potentiometer adjustable from 150 mV to 30 V

Sub-D-F connector

- Input sensitivity for 0 dB reading RCA:

Impedance:

Sub-D Input sensitivity for 0 dB reading

Sub-D: Reference level:

Max. input level:

+6 dBu (1,55 V)

> 10 kOhm

via software adjustable from 0 to +10 dBu

+24 dBu

Impedance: > 10 kOhm, electronically balanced

Digital Inputs/Outputs

Sampling rates:

1 digital S/PDIF input, RCA, unbalanced, 75  $\Omega$ 

1 digital S/PDIF ouput, RCA

TM3:

1 AES3 input, transformer balanced, 110  $\Omega$ , Sub-D-F connector, 25-pin (in-/output)

TM3 Smart (TM3S):

3 AES3 inputs, transformer balanced, 110  $\Omega$ , Sub-D-F connector, 25-pin (in-/output)

44.1, 48, 96 kHz, synchronisation to digital input

#### PPM/True Peak Display

General

Input sources: analog and/or digital

Peakmeter: TM3:

2-channel Stereo for the defined Stereo channel pair L/R

TM3 Smart (TM3S):

2-channel Stereo up to 6 channels, 5.1

Display: Peak level

Peak hold (selectable color)

• Numerical value of the display

• Gain (+20 dB, +40 dB acc. to standard) Functions:

Peak hold on/off Memory

Reset

**Analog Peakmeter** 

Analog scales: • DIN5: +5 .. -50 dB,

• Nordic: +12 .. -42 dB, BR IIa: 7 .. 1 (British),

BR IIb: +12 .. -12 dB (British),

■ Zoom10: +10 .. -10, Zoom1: +1 .. -1,

SMPTE24: +24 .. -30

■ SMPTE20: +20 .. -40

NHK

Integration time: acc. to standard or 20 ms, 10 ms, 1 ms, 0,1 ms 1, 2, 4, 10, 20, 30 s, manual reset or off

Peak hold indicator:

**Digital Peakmeter** 

Word width: 24 bit

Digital scales: • TP60: +3 .. −60 dB

TP20: +3 .. -20 dB Dig60: 0 .. -60 dB

Dig20: 0 .. -20 dB Dig0: +18 .. 0 dB

Dig18: +18 .. -18 dB

Dig40: +20 .. -40 dB

ARD9: +9 .. -60 dB

DIN5: +5 .. -50 dB,

DIN10: +10 .. -50 dB,

Nordic: +12 .. -42 dB,

BR IIa: 7 .. 1 (British),

BR IIb: +12 .. -12 dB (British), Zoom10: +10 .. -10,

Zoom1: +1 ... -1,

Headroom/Headroom Ref:adjustable in the range from 0 to −20 dB in

steps of 1 dB

Operation field:

adjustable in the range from 0 to -20 dB in

steps of 1 dB

Integration time (Attack): acc. to corresponding standard or selectable:

> Sample, 20 ms, 10 ms, 1 ms, 0.1 ms +20 dB, +40 dB (acc. to standard)

High-pass filter: Off, 5 Hz, 10 Hz, 20 Hz

Peak hold indicator: 1 s, 2 s, 4 s, 10 s, 20 s, 30 s, manual reset or off

Over indicator hold time: 1 s or manual

Over indicator PPM

- Threshold: Full Scale, Full Scale -1LSB, Full Scale -2LSB,

-0.1 dBFS, -0.5 dBFS, -1 dBFS, -2 dBFS,

-3 dBFS

- Attack time: 1 to 15 samples

- Word width: 16 to 24 bit, selectable

Over indicator True Peak

- Threshold: adjustable

**AES3 Status Monitor** 

Display:

Gain:

· channel data are displayed as plain text, hex

or binary

· Channel selectable

Audio bit activity

Hardware status

Global Keyboard

The Global Keyboard is used for control of defined functions in multiple instruments, and for preset recall. It also allows the external control with the integrated GP IO interface.

# Loudness and SPL Display

EBU R128 Loudness Mode

ITU-R BS.1771 Loudness Mode

ATSC A/85 Loudness Mode

ARIB Loudness Mode

**OP-59 Loudness Mode** 

**AGCOM Loudness Mode** 

**CALM Loudness Mode** 

>

#### **Customer Specific Loudness Mode**

Display:

• Bargraphs for each single channel (can be combined with PPM bargraphs)

M bargraph (Momentary value)

S bargraph (Short - shortterm value)

I-Bargraph (Integrated - long term value)

Red scale markers for 0 LU thresholds

Numerical display: Short, Integrated, Momentary, LRA values

Maximum values for True Peak (TPmax), Momentary (Mmax), Short (Smax)

Duration of Integrated measurment (I-time)

Scales: \*) Loudness scales:

EBU+9: +9 .. -18 LU

EBU+18: +18 .. -36 LU

EBU+9a: 14 .. -41 LUFS

■ EBU+18a: -5 .. -59 LUFS

• EBU0: 0 .. −60 LUFS ITU+9: +9 .. -18 LU

• ITU0: 0 .. –30 LKFS

ATSC0: 0 .. -60 LKFS

ATSC0a: 0 .. -30 LKFS

Weighting filter: K filter acc. to ITU-R BS.1770

Target Level: \*) -23 LUFS; adjustable in the range from -10 to

-30 LUFS

Time & Gate Momentary: \*)

- Window Time (SQR): adjustable in the range from 200 ms to 1000

ms in steps of 100 ms

IEC 125 ms Fast, 250 ms (IRT), 500 ms, 750 - Integration (IIR):

ms, IEC 1000 ms Slow, 1500 ms, 2000 ms

selectable

Time & Gate Short: \*)

- Integration Time:

3 s; time window adjustable in the range from 1

to 20 s in steps of 1 s

Time & Gate Integrated: \*)

- Silence Gate:

-70.0 LUFS; adjustable in the range from -80.0

LUFS to -40.0 LUFS in steps of 0.5 LUFS,

switchable

- Relative Gate:

-10.0 LU; adjustable in the range from -40.0 LU to 0 LU in steps of 0.5 LUFS, switchable

Level adjustment for the

summation: \*)

■ 0.0 dB (L, R, C), adjustable between -3 and

+3 dB in steps of 0.5 dB

+1.5 dB (LS, RS), adjustable between -3 and

+3 dB in steps of 0.5 dB

Off (LFE), selectable: Off, 0 dB, 10 dB

acc. to standard; tolerance above the Target Level, adjustable from 0 to +10 LU in steps of

Lower tolerance:

Upper tolerance:

acc. to standard; tolerance below the Target

Level, adjustable from 0 to -12 LU in steps of

\*) Depending on the used loudness standard not all of the listed settings are available.

#### Loudness Test Time Control

Settings for operating automatic, semi-automatic or manual loudness measurements.

Start:

Autostart after preset load, autostart with gate, - Functions:

autostart with gate and autoreset, manually via

keys or GPI

- Level for gate: -70,0 LUFS/LKFS; adjustable from -85 to -10

LUFS/LKFS in steps of 0.5 LUFS/LKFS

Stop:

- Functions: manually via keys or GPI, autostop with gate,

autostop with gate and time

- Level for gate: -70,0 LUFS/LKFS; adjustable from -85 to -10

LUFS/LKFS in steps of 0.5 LUFS/LKFS

- Time for gate: 1 s; adjustable from 1 to 15 s in steps of 1 s

#### Loudness Range Instrument (LRA)

Graphical display of the Loudness Range Display: Mode: selectable: LRA Bar, MagicLRA, MagicLRA + I,

MagicLRA + I + Num

selectable: 6 LU, 10 LU, 20 LU, 30 LU Scale range:

LRA low range: 2 LU; adjustable in the range from 1 to 20 LU in

steps of 1 LU

Comfort zone: 4 LU; adjustable in the range from 1 to 20 LU in

steps of 1 LU

LRA high range: depends on the selected scale range and the

spread of the comfort zone

Colors: selectable for each range

# **SPL Meter Mode**

Display:

· Bargraphs for each single channel (can be combined with PPM bargraphs)

Summation bargraph

Reference point: adjustable in the range from 68 dB to 88 dB in

steps of 1 dB

Linear, A (Leq(A)), C, CCIR (Leq(M)), k Weighting:

Integration time: Fast (125 ms), Slow (1 s)

TM3-SW6UPG (Software Licence, included in TM3 Smart) Software licence to upgrade the 2-channel version TM3 with 6-channel signal processing (2-channel Stereo, 1- to 6-channel, 5.1) and Dialnorm. When purchasing the licence, send in the internal generated licence request file. After the transmission of the returned licence file to TM3 the features of the 6-channel version can be permanently activated.

#### TM3-SWTCR: Timecode Reader (Software Licence, included in

TM3 Smart)

Decoding and display of LTC timecode.

Display: numerical display of LTC (from analog or digital

sources)

LTC (fixed), instrument selectable when creating Mode:

a Non-Audio group

one analog or digital channel selectable Input:

selectable, 32 colors Colors:

TM3-SWMC: Moving Coil (Software Licence, included in

Expands the function set of TM3 with the Moving Coil instrument for the display of needle instruments for up to 2-channel Stereo with different scales.

PPM (L/R), PPM (M/S), VU, Loudness, PPM + Туре: Loudness (L/R; M, S, or I), selectable

PPM:

Dual Dual + M/S horizontal Dual + M/S verti-- Ch. arrangement: cal, Stereo horizontal, Stereo vertical

- Scales: BR IIa: 7..1, BR IIa ext: 7..1

BR IIb: +12..-12 dB, BR IIb ext: +12..-12 dB Sample (digital only), 0.1 ms, 1 ms, 10 ms, 20 - Integration time:

ms. 150 ms - Headroom Ref:

available with digital sources only: -10 dB; adjustable from 0 to -20 dB in steps of 1 dB

only available, if M/S type is selected: M3, M6 - S mode: - Peak indicator: Off, Peak, True Peak, BR Peak - BR Peak Threshold: 6 dB.

BR IIa: adjustable from 4 to 7 dB in steps of

• BR IIb: adjustable from 0 to 12 dB in steps of 1 dB

VU:

- Ch. arrangement: Stereo horizontal, Stereo vertical VU (-20 to +3 dB)- Scale analog: VU Digital (-20 to + 3 dB) - Scale digital:

- Lead: 0 dB, adjustable from 0 to 12 dB in steps of 1 dB

- Peak indicator: Off, Peak, True Peak

Loudness:

Dual, Stereo horizontal, Stereo vertical - Ch. arrangement:

- Scales: acc. to Loudness settings - Integration time: acc. to standard

- Peak indicator: Off, no selectable option available PPM + Loudness:

switchable

- Ch. arrangement: Dual-PPM (as described above) with additional Loudness display (BBC) for M, S, or I (selectable) in one instrument

- Scales: PPM: see above

> Loudness: +9 to -9 LU fixed (mid of scale corresponds to Target Level)

Numerical display:

TM3-SWB1: Software Bundle (Licence upgrade, included in

Licence upgrade for expanding TM3 with all licences (details see Optional Software Licences) and for expanding the completed feature set with the Chart instrument. When a software bundle has been installed, upcoming instruments and functions can be added via firmware update.

acc. to TM3-SW6UPG, TM3-SWMC, TM3-Display:

SWTCR, and Chart instrument

Chart

Display:

Colors:

Description: Loudness Chart instrument for displaying and

analyzing the course over time of a loudness measurement directly on the display.

Loudness Chart Instrument

Functions: Coordinate system displaying a graph with the course over time of one of the measured

values TP, M, S, or I

Relative Gate view switchable

Adjustable time ranges

Vertical Integrated bargraph switchable

Adjustable tolerance levels

Course over time of the selected value with

color filling or as line

Tolerance Marker Position of the Relative Gate (doubled hori-

zontal line)

· Vertical I bargraph

• Fill: Adoption of the corresponding colors of

the Loudness Sum instrument

· Line: cyan (M), light red (S), green (I),

yellow (TP) Tolerance Marker: coordinate system turns

to light grey except the corridor defined by

the tolerance settings Relative Gate: white

Time range presets: Time range select: Upper tolerance:

1 m; 1 m, 5 m, 1 h selectable

via preset or onscreen during normal operation as defined in the Loudness/Tolerance menu of each audio group; tolerance above the Target

Level

as defined in the Loudness/Tolerance menu of Lower tolerance: each audio group; tolerance below the Target

#### **Items of Delivery**

TouchMonitor TM3:

- 2-channel Stereo version
- Basic software (see chapter "Software")
- TM3 display unit with 4.3" touch screen in a table-top case with fixed connector cable (approx. 2 m)
- Interface box, connected with display unit
- Mains adapter, manual

Order no.: TM3

TM3 Smart:

- 6-channel version (2-ch. Stereo, 1- to 6-channel, 5.1)
- Extended software including all available licences and Chart instrument
- TM3 display unit with 4.3" touch screen in a table-top case with fixed connector cable (approx. 2 m)
- Interface box, connected with display unit
- Mains adapter, manual

Order no.: TM3S

#### **Additional Hardware Options**

- Option for 2U rack mounting TM3-2U, allows mounting TM3/TM3S into rack frame TM3-MA2U or into other appropriate mechanical environments. It can only be ordered together with a TM3, or TM3S device. Then, a display with mounting frame, mounting material, and an USB extension cable is part of delivery instead of the TM3 display unit in a table-top frame.
- 2U rack carrier TM3-MA2U, 19"/2U rack carrier/mounting frame to be fitted with up to two TM3 series units which must feature the TM3-2U option.

### **Optional Software Licences**

(for TM3, included in TM3 Smart)

 Software licence TM3-SW6UPG for the upgrade of TM3 with 6-channel processing and Dialnorm instrument


- Software licence TM3-SWMC for the upgrade of TM3 with the Moving Coil instrument
- Software licence TM3-SWTCR for the upgrade of TM3 with the Timecode Reader instrument for decoding and displaying LTC timecode
- Software bundle TM3-SWB1, licence upgrade for expanding TM3 with licences TM3-SW6UPG, TM3-SWMC, and TM3-SWTCR, and with the Loudness Chart instrument for displaying the course over time of a loudness measurement.

When the software bundle has been installed, upcoming instruments and functions can be added via firmware update.

#### **Optional Accessories**

- Extension cable 1161 for TM3 interface box, 10 m, to enlarge the distance between TM3 display unit and TM3 interface box up to 12 m. Set includes required f-f adapter
- Snake cable 1162 (2 m) for TM3 interface box, distributes 25-pin. Sub-D-M to 2 x XLR-F (analog inputs), 3 x XLR-F (AES3 inputs), and 3 x XLR-M (AES3 outputs)
- Metal mounting plate 1166 for TM3 display unit to be mounted with 3/8" holds (e. g. gooseneck, mic stand)
- Wide voltage power supply 1178-R
  (100 240 V AC/24 V DC 2,71 A, table-top
  unit with corresponding mains cable for
  different power systems)

# Block Diagram



 $^{\circ}$  03/2017 | Technical changes without prior notice.

